


BIM Workflows for the Structural Engineer: Design to Fabrication

Brian E Johnson, PE

Technical Specialist | @bedwardj







About the speaker

Brian E Johnson, PE

Brian is a Technical Specialist for Autodesk. He is an expert in structural modeling and design using Revit and Robot Structural Analysis. Brian is a licensed structural engineer with over 15 years of building design and consulting experience. During that time he worked as a Project Manager and Principal on a variety of structures. He earned a B.S. in Civil Engineering from the University of Texas at Austin.

Connected Workflow





Download the Addins

MANAGE.AUTODESK.COM

Robot Structural Analysis Link for Revit 2021*

Advance Steel Extension for Revit 2019–2021 [Hotfix 1]

Revit 2018 Steel Connections

APPS.AUTODESK.COM

Structural Analysis Toolkit 2018–2020*

Robot-AdvanceSteel Link 2018-2021

Advance Steel 2018 Extension

*

Only needed if Robot Structural Analysis Professional is not installed alongside Revit.

*

Functionality ships with Revit 2021.

Design with Revit

SEND TO RSA PRO

UPDATE

SEND TO REVIT

Backcheck & adjust if needed.

Optimize & code check.

DESIGN

Add loads & adjust properties.

Analyze.

ITERATE

REPEAT

Coordinate design revisions

from Client in Revit.

Repeat.

Prepare Sheets.

CREATE/REVISE

CREATE REVIT MODEL

Model primary structural

framing in Revit.

Adjust the Analytical Model.

Design with Advance Steel

DESIGN

SEND TO RSA PRO

UPDATE

SEND TO ADVANCE STEEL

Backcheck & adjust if needed.

Optimize & code check.

Add loads & adjust properties.

Analyze.

ITERATE

REPEAT

Coordinate design revisions

from Client in Advance Steel.

Repeat.

Generate Piece Marks.

Process Engineering Drawings.

CREATE/REVISE

CREATE ADVANCE STEEL MODEL

Model primary structural framing in Advance Steel.

Note the System lines represent the Analytical Model.

Fabrication with Advance Steel

CONNECT

complete.

Steel.

MODEL CONNECTIONS IN REVIT

Perform when design is (near)

Optionally, connect in Advance

Model connections.

Design joints with loads sent from RSA.

CONNECT

Model miscellaneous steel.

DELIVER

FABRICATE

DOCUMENT

PREPARE DRAWINGS

Generate Piece Marks.

Create Camera Views.

Process Shop Drawings.

Process Erection Drawings.


Generate NC files.


Generate BOM lists.

Generate DXFs.

SEND TO ADVANCE STEEL

Model plateworks.





Direct Transfer

Revit and Robot Structural Analysis must be installed on the same computer.


Intermediate File Transfer

Use when only one application is on the computer or when the intermediate file is desired as secondary backup.

Advance Steel Transfers

The interface and intermediate files are different than the those with Revit. The processes are virtually identical.


- Review the options
- Export
- Synchronize
- Accept or reject updates
- Complete the transfer



Pre-Transfer Activities

Model the structure, of course!


- Review and adjust the Analytical Model (Revit) or System lines (Advance Steel)
- No adjustments needed for sending from Robot
 Structural Analysis



Post-Transfer Activities

Some of these activities may be performed in either Revit or RSA. Others are simply the other model preparations needed for structural analysis.

- Edit end releases of members
- Add load cases, loads, and load combinations
- Edit any advanced member properties
- Edit mesh settings for panel elements
- Edit design parameters/criteria for steel and concrete elements





Model Hygiene

A change in process requires forethought and planning for success.

- Inspect both 3D and 2D views of just the analytical elements.
- Compare the analytical elements to the "physical" elements in a 3D, Wireframe model.
- Adjust the analytical model elements using the tools in the Analyze ribbon and properties palette.
- Disable the analytical model for non-structural elements such as veneer walls or slabs-on-grade.
- Check and resolve any warnings related to the analytical model elements

Content Libraries

A change in process requires forethought and planning for success.


- Align Revit family Types with RSA and Advance Steel section names.
- Align Revit material Types with RSA and Advance Steel material names.
- Load Case and Load Combination names in Revit and RSA.
- Create custom content in Revit, RSA, and/or Advance Steel PRIOR to transfers.
- Experiment with transfers of compound and built-up shapes between applications.

Protocols

Who does what and in which software?


- Model grids, levels, framing and foundations in Revit.
- Model & update Boundary Conditions, Load information, and End Releases in RSA
- Model connections in Revit if needed for clash coordination during design.
- Model remaining connections in Advance Steel.
- Update Revit with optimized members from RSA
- Update design changes from the Architect or Owner in Revit





File Locking:


- Check out / Check in workflow
- Prevent overwrite race condition



File Versions:

- Compare documents
- Regress to prior version


Compare Close compare






Share documents with:

- BIM 360 team members
- Public



Coordinate with:

- Architecture & MEP models
- Steel fabrication & steel joist models




Reviews with BIM 360

Review & Approval

Use BIM 360 Markups, Issues for:


- Design reviews
- Internal coordination
- Shop drawing reviews



Review & Approval

Assign Issues for:


- To do lists & action items
- Project progress & status
- Accountability



Review & Approval

Use Review workflows for:

- Formal QA/QC process
- Document release







Autodesk and the Autodesk logo are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders. Autodesk reserves the right to alter product and services offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document.

© 2020 Autodesk. All rights reserved.

